

NOTE: This installation is to be completed by an Authorized Dealer or Professional Service Technician. For questions regarding installation or warranty, call CDI Tech Support at 866-423-4832. **Do not return to the Dealer or Distributor where the part was purchased. Contact CDI Electronics Directly for Return Material Authorization.**

CDI P/N 413-9915 Wiring Harness 2 Cyl.

This unit will replace P/N's: 582061, and 583005

WARNING! This product is designed to be installed by a professional marine mechanic. CDI Electronics cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.

Installation

1. Disconnect battery.
2. Remove original wiring harness. Be sure to make note of wire routing.
3. With old wiring harness removed clean all connection points to verify good connection of new wiring harness.
4. Install new wiring harness in the same position as original wiring harness.
5. Verify proper placement of all wires. Reconnect battery.
6. Wire color chart.
 - A) **Red/Purple**- Power side of starter solenoid
 - B) **Red**- Splits off of Red/Purple, goes to terminal block then to rectifier
 - C) **Yellow/Red**- Switched power to starter solenoid
 - D) **Black**- Ground wire
 - E) **Gray**- Tach wire from rectifier
 - F) **Black/Yellow**- Plugs into Power Pack connector
 - G) **Violet/White**- Choke solenoid
 - H) **Tan**- Temperature sensor

