

MERCURY MARINE INSTALLATION/TROUBLESHOOTING GUIDE

Mercury Marine P/N: 300-888791

Notice: This coil/bracket assembly replaces the Blue and Black Force Ignition Coils, P/N's: 684475 and 615475.

Warning! This product is designed for installation by a professional marine mechanic. Mercury Marine cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.

Installation

1. Remove the original coil, saving the original bolts, and cut off the primary lead (usually a white or blue striped wire) as close to the coil as possible.
2. Strip approximately ¼" of insulation from the primary lead.
3. Slide the heat shrink on the wire, then crimp and solder the #6 terminal to it.
4. Mount the new coil assembly from the bottom side of the plate using the original bolts.
5. Connect the new coil wire from the coil to the spark plug.
6. Connect the primary lead from the pack to the coil.

MERCURY MARINE INSTALLATION/TROUBLESHOOTING GUIDE

Mercury Marine P/N: 300-888791

Notice: This coil/bracket assembly replaces the Blue and Black Force Ignition Coils, P/N's: 684475 and 615475.

Warning! This product is designed for installation by a professional marine mechanic. Mercury Marine cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.

Installation

1. Remove the original coil, saving the original bolts, and cut off the primary lead (usually a white or blue striped wire) as close to the coil as possible.
2. Strip approximately ¼" of insulation from the primary lead.
3. Slide the heat shrink on the wire, then crimp and solder the #6 terminal to it.
4. Mount the new coil assembly from the bottom side of the plate using the original bolts.
5. Connect the new coil wire from the coil to the spark plug.
6. Connect the primary lead from the pack to the coil.